


PULL OUT SHELF INSTALLATION

Contents:

(1) Dovetailed wood drawer tray, (1) left hand drawer glide, (1) right hand drawer glide, (1) left hand rear socket, (1) right hand rear socket, (1) hardware bag including: (2) spacers and (4) screws



Step 1:


Install rear sockets by screwing two 1" screws into the rear socket in the back of the cabinet. Install at the desired height of the roll out tray and be sure to install square with the front of the face frame. Be sure to account for 1/4" for the spacer. Perform on both the left and right hand side.

Step 2:

Insert left and right handed glides into the rear sockets.

Step 3:

Attach the front of the glide to the front frame of the cabinet, placing the spacer between the glide and the cabinet. Do for both the left and right hand sides.



Step 4:

Measure the distance between the two glides at both the front and back. Ensure these dimensions are equal.

Step 5:

Insert the drawer tray into the installed glides. Ensure that the drawer is completely seated on the track, and not just sitting on the outside edge.

Pull Out Shelf Dimensions	
POS 12	7 1/2" x 21 3/4"
POS 15	10 1/2" x 21 3/4"
POS 18	13 1/2" x 21 3/4"
POS 21	16 1/2" x 21 3/4"
POS 24	19 1/2" X 21 3/4"
POS27	22 1/2" X 21 3/4"
POS 30	25 1/2" X 21 3/4"
POS 33	28 1/2" X 21 3/4"
POS 36	31 1/2" X 21 3/4"